

Table of Contents

1 Preface	7
• About this Manual.....	7
• Copyright	7
• Federal Communications Commission (FCC) Compliance	7
• Declaration of Conformity	8
• Trademark Recognition.....	8
• Safety and Handling Precautions	8
• Camera Information	8
• Battery Information	9
2 Introduction	10
• Camera Features	10
• Package Contents	11
• Camera Views.....	12
• Camera Buttons.....	13
• Navigation Control	13
• Camera Memory.....	15
Internal memory	15
External storage.....	15
3 Getting Started.....	16
• Attaching the Wrist Strap	16
• Inserting the Battery.....	16
• Inserting an SD/SDHC Memory Card	17
• Turning the Power On and Off	18
• Initial Settings	18
Setting the Language	18
Setting the Date & Time	18
• Modes.....	19
Record mode	19
Playback mode	19

Switching between Record mode and Playback Mode	19
Selecting the Record mode options section	19
4 Using the LCD Screen	20
• LCD Screen Layout	20
Record Mode Screen Layout.....	20
Playback Mode Screen Layout.....	22
Changing the LCD Screen Display	25
5 Recording Photos, Videos and Voices	27
• Taking Photos	27
• Using the Image Stabilizer	28
• Setting the Zoom Control	28
• Using Flash	29
• Setting the Focus Mode	30
• Using the Function Manual	30
My Mode	31
Resolution	31
Quality	32
EV Compensation.....	32
White Balance	33
ISO	34
Metering.....	34
Color Mode.....	35
• Using the Record Manual	36
• Setting Scene Mode	36
Using Smile Capture Mode	39
Using Intelligent Scene Mode	40
Using Blink Detection Mode	42
Using Aperture Priority Mode.....	43
Using Shutter Priority Mode.....	43
Using Manual Exposure Mode	44
• Setting the Drive Mode	45
• Setting the AEB	46
• Setting the AF Area	46
• Setting the AF Lamp	47
• Setting Sharpness	47

• Setting Saturation	48
• Setting Contrast	48
• Setting the Digital Zoom	49
• Setting the Date Stamp	49
• Setting the Auto Review.....	50
• Recording Movies.....	51
Setting Movie Size	51
YouTube Mode	51
• Recording Voices.....	53
6 Playback	54
• Viewing in Single Navigation.....	54
• Viewing Thumbnails.....	54
• Zooming images	55
• Playing Movies	56
• Playing Voice Recording.....	57
• Playing Voice Memo	58
• Deleting an Image/Video/Audio	58
Using the Delete Button.....	58
• Setting Playback Menu	59
• Setting Slideshow.....	60
• Deleting Files	61
To delete a photo/video/audio clip	61
To delete a single file.....	61
To delete attached voice memo	62
To delete multiple files	63
To delete all files.....	63
• Protecting/Unprotecting Files	63
To protect files.....	63
To protect/unprotect a single file	63
To protect/unprotect multiple files.....	64
To protect all files	64
To unprotect files.....	64
• Red-Eye Correction.....	65
• Voice Memo.....	66

• Photo Editing	66
• Trim	68
• Resize	69
• Setting Startup Image	70
• Setting DPOF	70
To set DPOF on a single image/all image	71
To reset DPOF	71
• PictBridge	71
7 Using the Setup Menu	72
• Setting Sounds	72
• Setting Power Save	73
• Setting LCD Save	73
• Setting Date & Time	74
• Setting Language	74
• Setting File Numbering	74
• Setting TV Out	75
• Setting LCD Brightness	75
• Setting Battery Type	75
• Setting Memory Kit	75
• Reset All	76
8 Installing the Software onto a Computer	77
• Installing the Software	77
• Software Included with Your Camer	78
• Fast and Easy YouTube™ Upload	79
• System Requirements	79
• Uninstalling Polaroid i1037 Camera Driver	80
9 Making Connections	81
• Connecting the Camera to a TV	81
To connect your camera to a TV	81
• Connecting the Camera to a PC	81
• Connecting the Camera to a Printer	82
10 Appendix	83
• About Folder and File Names	83

Folder Structure.....	83
File Naming	83
11 Troubleshooting	85
12 Getting Help.....	86
• Polaroid Online Services	86
• ArcSoft Software Help.....	86
13 Specifications.....	87
• Specifications.....	87
• Camera Default Settings.....	89

• About this Manual

This manual is designed to assist you in using your new digital camera. All information presented is as accurate as possible but is subject to change without notice.

Copyright

This manual contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer.

© Copyright 2009

Federal Communications Commission (FCC) Compliance

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: A shielded-type power cord is required in order to meet FCC emission limits and to prevent interference to radio and television reception. Use only shielded cable to connect I/O devices to this equipment. Any changes or modifications not expressly approved by the manufacturer may void your warranty and service agreement.

Declaration of Conformity

This device complies with Part 15 of the FCC rules. Operation is subject to the following conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

Trademark Recognition

Windows 98/2000/ME/XP are registered trademarks of Microsoft Corporation in the United States and/or other countries. Windows is an abbreviated term referring to the Microsoft Windows Operation System. All other companies or product names are trademarks or registered trademarks of their respective companies.

• Safety and Handling Precautions

Camera Information

- Do not disassemble or attempt to service the camera yourself.
- Do not expose the camera to moisture, or extreme temperatures.
- Allow the camera to warm up when moving from cold to warm temperatures.
- Do not touch the camera's taking lens.
- Do not expose the lens to direct sunlight for extended periods.
- Do not use abrasive chemicals, cleaning solvents or strong detergents to clean the product. Wipe the product with a slightly damp soft cloth.

Battery Information

- Turn off the camera before installing or removing batteries..
- Use only the provided batteries or type of battery and charger that came with your camera. Using other types of batteries. or charger may damage the equipment and invalidate the warranty.
- If applicable, when using Li-ion battery in this product, ensure that they are inserted correctly. Inserting the battery upside down can cause damage to the product and possibly cause an explosion.
- When the camera is used for an extended period of time, it is normal for the camera body to feel warm.
- Download all pictures and remove the batteries from the camera if you are going to store the camera for a long period of time.
- Ensure you select the correct battery type in the setup menu and use a fully charged or fresh battery.
- There is a risk of damaging the product or personal injury if the battery is replaced by an incorrect type. Dispose of used batteries properly.

Need help with your digital camera?

Call our toll-free customer service number. Look for the insert with this icon:



Or visit www.polaroid.com.

2 Introduction

Congratulations on the purchase of your new Polaroid digital camera. This manual provides you step-by-step instructions on how to use your camera, and is intended for your reference only.

• Camera Features

- 12 megapixels resolution
- Up to 3x optical zoom and 5x digital zoom
- 1/2.3 inch CCD image sensor
- 2.7 inch color LCD display
- 32MB internal flash memory with optional external SD/SDHC card
- Supports up to 4GB of SD card, and up to 32GB of SDHC card
- Sleek metallic finish
- Easy-to-use button interface
- DCF, DPOF, PictBridge compatibility
- Slideshow feature to review your pictures and movies
- *A/V* output to view your pictures and movies on your TV
- USB port to transfer photos and movies to your PC

Need help with your digital camera?


Call our toll-free customer service number. Look for the insert with this icon:



Or visit www.polaroid.com.

• Package Contents

Please check the contents of your camera package. It should contain:



i1237



Quick Start Guide



The CD-ROM includes
Polaroid i1237 Camera Driver (PC)
ArcSoft MediaImpression™; (PC/Mac)
ArcSoft Print Creations® (PC/Mac)
Adobe® Acrobat® Reader™ (PC/Mac)
User Guide (in PDF format)



Wrist Strap




2 x AA Batteries




USB Cable

• Camera Views


1. Shutter button
2. Flash
3. Self-timer LED
4. Image Stabilizer Button
5. Power button
6. Speaker
7. USB/AV port
8. Lens
9. Microphone



10. Zoom out / Thumbnail button
11. Playback mode button
12. Power / Auto Focus LED
13. Macro / Left button
14. Stop / Down button
15. Menu button
16. Zoom in button
17. Wrist strap holder
18. Play / Pause / Up button
19. Flash / Right button
20. Set / Display button
21. Mode / Scene button



22. SD card door
23. Tripod socket
24. Battery Door




• Camera Buttons

Your camera is equipped with different buttons for ease of use.

Button	Description
Power	Press to turn the power on or off.
Image Stabilizer	The image stabilizer sets the optimal ISO value according to light levels to compensate for camera shake. Press to set stabilizer on/off.
Shutter	Press to capture an image or start/stop recording a video or audio clip.
Play	If the camera is turned off, press and hold to turn on camera in Playback mode. If the camera is turned on, press to toggle camera between the Playback or Record mode.
Zoom	Press the zoom buttons to change zoom magnification.
Menu	Press to enter the menu.
Function/ Delete	In the Record mode, press to enter function menu. In the Playback mode, press to delete an image, video or audio clip.

• Navigation Control

The 4-way Navigation Control and the OK button allows you to access the various menus available from the On Screen Display (OSD). You can configure a wide range of camera settings to ensure the best results for your photos and videos. Further functions of these buttons are as follows:



Button	Usage
OK	1. Confirms a selection when using the OSD menus.
Flash/ Right	<ol style="list-style-type: none"> 1. In the Record mode, press to scroll through the flash mode options(Auto, Anti Red-eye, Fill, Slow Sync and Off) 2. In the Playback mode, press to view the next image, video or audio clip. 3. In the Playback Video mode, press to fast forward video playback 4. In the Menu, press to enter the submenu or to navigate through the menu selections.
Macro/Left	<ol style="list-style-type: none"> 1. In the Record mode, press to turn on/off Macro. 2. In the Playback mode, press to view the previous image, video or audio clip. 3. In the Playback Video mode, press to rewind video playback 4. In the Menu, press to exit a submenu or to navigate through the menu selections.
Up/Face Tracking/ Rotate	<ol style="list-style-type: none"> 1. In the Menu, press to navigate through the menu and submenu selections. 2. In the Record mode, press to turn the face tracking function on or off. 3. In the Playback Video/Audio mode, press to Start/Pause video or audio playback. 4. In the Playback photo mode, press to rotate the image clockwise 90 degrees with each press of the button. This feature is applicable for still images only.
Display/ Down	<ol style="list-style-type: none"> 1. In the Playback mode, press to change the LCD screen display to show or hide OSD icons. 2. In the Record mode, press to change LCD screen display to show or hide OSD icons and guide lines. 3. In the Menu, press to navigate through the menu and submenu selections. 4. In the Playback Video/Audio mode, press to stop video/audio playback.

- Camera Memory

Internal memory

Your camera has 32MB of internal memory. Users can store images up to 10MB. If there is no memory card inserted in the camera, all images, videos and audio clips recorded are automatically stored in the internal memory.

Expanding Your Camera's Memory


Your camera supports SD cards of up to 4GB in size. It also supports SDHC card with a maximum capacity of 32GB. If there is a memory card inserted in the SD card slot, the camera automatically saves all images, videos and audio clips in the external storage card.



NOTE:

- Not all cards may be compatible with your camera. When purchasing a card, please check the card's specifications and take the camera with you. Polaroid branded memory cards are recommended.

3. Flip the door back into place as shown in the illustration and slide the locking tab in the direction of the arrow.






• Inserting a SD/SDHC Memory Card

Expand your camera's memory by using SD or SDHC memory cards. Your camera supports SD cards of up to 4GB and SDHC cards of up to 32GB in size.

Follow these instructions to insert the SD/SDHC card.

1. Make sure the power is off before inserting a SD/SDHC memory card.
2. Swing on the SD card door in the direction of the arrow and flip the door open.
3. Insert the SD/SDHC card into the memory card slot label side up.
4. Push the SD/SDHC card into the memory slot until it clicks into place.
5. Close the SD card door as shown in the illustration.



To remove the SD/SDHC card, gently push the card inward with your finger and release it. Pull out the card carefully.

• Turning the Power On and Off

There are two ways to turn on the camera:

- Press and hold the Power button. The start up image displays briefly and the startup sound plays if enabled. The zoom lens extends and the camera is turned on in the Record mode.
- Press and hold the Playback button. The camera is turned on in Playback mode. The zoom lens is not extended.

To turn off the camera, press the Power button.

See " Modes" on page 19 to know more about Record and Playback mode.

• Initial Settings

When you turn on your camera for the very first time, you will be asked to establish the initial settings of your camera.

When you turn the Power button on, the Language Menu is displayed on the LCD screen for you to setup your display language.

Setting the Language

1. Press ▲ or ▼ to move through the selections.
2. Press OK to select your language.

Setting the Date & Time

1. Press ▲ or ▼ to change the value of the date and time.
2. Press OK to apply.
3. If necessary, press MENU to close the menu.

Now, you are ready to start taking photos and videos.



NOTE:

- Holding down ▲ or ▼ changes the values continuously.
- If the battery is removed for more than 48 hours, the Date & Time will have to be reset.

• Modes

Your camera has two modes:

Record mode

- Set to the Record mode to capture still images, record videos and audio clips.
- Record mode can be further set to mode options like auto, movie and scene selection modes. See “ Selecting the Record mode options” below.

Playback mode

- Set your camera to Playback mode to view and edit captured images and playback videos and audio clips. You can also attach a voice memo to still images in this mode.


When you turn on your camera using the Power button, you are automatically in the Record mode.


Switching between Record mode and Playback Mode

Press the Play button to switch between Record and Playback modes.

Selecting the Record mode options section

Maximize the quality and ease of use of your camera by using the different mode options. The mode options allow you to capture images with preset settings according to the scene conditions.

1. Set the camera to Record mode.
2. Press MENU to launch Record Mode Menu.
3. Select Record Mode by pressing the DISP button once, and press  to enter its submenu.
4. Select a mode
5. Press the OK button to confirm your selection..



NOTE:

- For more information, see “ Using the Record Menu” on page 37.
- Use the 4-way navigation control to move through the menu selections.


4 Using the LCD Screen

The high resolution 2.7" LCD display shows all important information regarding your cameras' settings as well as the visual image of your photo or video. This display is called the On Screen Display or OSD.

• LCD Screen Layout

The following illustrations shows the LCD screen layout and the icon descriptions.

Record Mode Screen Layout




No.	Item	Description
1	Record Mode	Indicates the current record mode settings.
2	Flash	Indicates flash settings.
3	Self-timer / Burst	Indicates drive mode settings.
4	Zoom Indicator	Displays zoom.
5	Shots available	Indicates the remaining shots available.

No.	Item	Description
6	Battery	Indicates battery power level.
7	Storage media	Indicates current storage media in use.
8	Date stamp	Indicates whether the date stamp is enabled.
9	AEB	Indicates whether the AEB function is enabled.
10	Stabilizer	Indicates whether the image stabilizer function is enabled.
11	Saturation	Displays saturation settings.
12	Contrast	Displays contrast settings.
13	Histogram	Graphic display of ISO settings.
14	ISO	Displays ISO settings.
15	Focus area	Use to frame subject you wish to capture.
16	Shutter speed	Displays shutter speed settings.
17	Aperture size	Displays aperture settings.
18	Shake warning	Indicates that the camera is recommending that you enable the image stabilizer feature.
19	Macro	Indicates macro is enabled.
20	Exposure	Displays exposure value settings.
21	Face tracking	Indicates whether the face tracking is enabled.
22	White balance	Displays white balance settings.
23	Metering	Displays metering settings.
24	Sharpness	Displays sharpness settings.
25	Quality	Displays quality settings.
26	Resolution	Displays resolution settings.
27	AF lamp	Indicates AF lamp is enabled.

Playback Mode Screen Layout


The Playback mode display varies depending on the type of file being viewed.

Playback mode display of still images:




No.	Item	Description
1	Playback mode	Indicates playback mode.
2	Protect	Indicates the file is protected.
3	Audio clip	Indicates a file has a voice memo.
4	Button intro	Indicates the button to press on the camera to play a movie or audio file.
5	File no. / Total no.	Indicates the file number and the total number of files in the memory card.
6	Battery	Indicates battery power level.
7	Storage media	Indicates where images (data) are stored.
8	Recording information	Displays recording information of the file.
9	DPOF	Indicates the file is marked for printing.
10	Resolution	Displays image size.

Playback mode of videos:



No.	Item	Description
1	Playback mode	Indicates playback mode.
2	Protect	Indicates the file is protected.
3	Movie clip	Indicates the file is a movie.
4	Button intro	Indicates the button to press on the camera to play a movie or audio file.
5	File no. / Total no.	Indicates the file number and the total number of files in the memory card.
6	Battery	Indicates battery power level.
7	Storage media	Indicates where images (data) are stored.
8	Recording information	Displays recording information of the file.
9	Volume	Indicates volume settings.
10	Key indicator	Indicates the buttons to press on the camera to apply the functions.
11	Playing status	Displays playing status.
12	Played time	Indicates played time.

Playback mode of audio clips:



No.	Item	Description
1	Playback mode	Indicates playback mode.
2	Protect	Indicates the file is protected.
3	Button intro	Indicates the button to press on the camera to play a movie or audio file.
4	File no. / Total no.	Indicates the file number and the total number of files in the memory card.
5	Battery	Indicates battery power level.
6	Storage media	Indicates where images (data) are stored.
7	Recording information	Displays recording information of the file.
8	Volume	Indicates volume settings.
9	Key indicator	Indicates the buttons to press on the camera to apply the functions.
10	Playing status	Displays playing status.
11	Played time	Indicates played time.

Changing the LCD Screen Display

The type of information displayed on the LCD screen can be changed using the DISP button.

Press the DISP button repeatedly to change the LCD display from one type to another.


In Record Mode, the LCD display can be changed into any of the following:



OSD on



Full OSD on



Guide lines on



OSD off



NOTE:

- The OSD information may vary depending on the record mode type.
- Use the "Guide lines" to properly align your image for capture.

In Playback mode, the LCD display can be changed into any of the following:



OSD on



Full OSD on



OSD off



NOTE: LCD display cannot be changed for the following situations:

- Manual exposure mode
- Recording movie or audio clips
- Playing movie or audio clips
- Playing slideshow

Need help with your digital camera?

Call our toll-free customer service number. Look for the insert with this icon:



Or visit www.polaroid.com.

5 Recording Photos, Videos and Voices

• Taking Photos

Now that you are familiar with your camera, you are now ready to take your photos.

Taking photos with your camera is very simple.

1. Turn on the camera by pressing the Power button. By doing this, your camera is set to Record mode.
2. Frame your shot using the focus frame on the LCD display. See illustration on the right.
3. Press the shutter button halfway down. The camera automatically adjusts the focus and exposure. When the camera is ready to take the photo, the focus frame turns green, the shutter speed and aperture value are displayed. (When the focus frame is in red and the operation LED blinks, the subject is not in focus. Release the shutter button, recompose the scene and press the shutter button halfway to reset the focus.)
4. Press the Shutter button all the way down to capture your image.




When the shake warning icon  appears, hold the camera steady, with your arms at your side or use a tripod to stabilize the camera to prevent a blurry image. You may need to turn on the camera's flash or enable the Image Stabilizer feature to get a better picture.

• Using Flash

When taking pictures in difficult lighting conditions, use the Flash to get the correct exposure. This function cannot be activated when recording movies or continuous shooting.

To activate the Flash

- Press the Flash/Right button on your camera repeatedly until your desired flash mode is displayed on the LCD display.



Your camera is equipped with five flash modes:

⚡A Auto. The flash fires automatically whenever extra lighting is needed.

⚡👁 Red-eye reduction. The flash fires twice to reduce the red-eye effect.


⚡Always on. The flash always fires when you press the shutter button regardless of lighting conditions.

⚡SL Slow sync. The flash fires with a delay and uses slow shutter speed.

🚫 Off. The flash is turned off.

NOTE:

- Flash function is only available in shooting still images but not available in Burst and AEB modes.
- Do not charge the flash while pressing the zoom button. Charge the flash after releasing the zoom button if necessary.




• Setting the Focus Mode

This function allows users to define the type focus when recording a still image or a movie clip.


To set the Focus mode


- Press the Macro button repeatedly until the desired focus mode icon is displayed on the lower left corner of the LCD display.



Your camera supports the four focus modes:

Normal. With normal focus, the focus range starts from 0.4m(1.31ft). When the camera is set to Normal mode, there is no icon displayed on the screen.

 **Macro.** This mode is designed for close-up photography. If Macro is enabled, you can capture the detail and sharpness of a very close image. (Please refer to page 88 for the macro focus range).



Macro enabled

PF Pan Focus. When Pan Focus is set, the camera focuses on every object.

INF Infinity. When Infinity is set, the camera focuses on distant objects.



• Using the Function Menu

The Function Menu is used to adjust capture settings in Record Mode. It contains My Mode, Resolution, Quality, EV Compensation, White Balance, ISO, Metering, and Color Mode.


 Press the FUNC button of your camera to launch the Function Menu.

FUNC  Press the FUNC button again to close the menu.

- The Menu bar displays the current status of your camera settings. Only the available functions for the settings are shown as icon on the menu bar.

- The available options for each item on the menu bar are shown in the Menu options.
- Use the  or  key to move through the menu selections then press the OK button to save and apply changes.

Menu bar












• My Mode

The My Mode function displays the 6 most recent modes used in order. When you move through the different modes in the menu options, the items on the menu bar changes to the corresponding available settings.

• Resolution

The Resolution function is used to set the resolution before you capture the image. Changing the resolution affects the number of images that can be stored in your memory card. The higher the resolution, the more memory space is required. The table below shows the resolution values for still images.

Icon	Pixel Size	Icon	Pixel Size
	4000 x 3000		2048 x 1536
	4000 x 2672		1920 x 1080
	3264 x 2448		640 x 480
	2592 x 1944		






• Quality

The quality determines the amount of compression applied to your photos. More compression results in a more detailed image. However, the higher the quality, the more memory space is required in your memory card.

• EV Compensation

EV stands for Exposure Value. In difficult lighting conditions, the auto exposure function of your camera may be misled into giving the wrong readings. The EV Compensation function allows you to adjust the exposure value and correctly expose your images. Available for still images only.


- To adjust EV settings, press the  or  keys to increase/decrease the value. As you adjust the settings, the LCD display displays the adjusted image when applying these EV settings. Press the OK button to save and apply changes.
- The available settings are: 0EV, +0.3EV, +0.7EV, +1.0EV, +1.3EV, +1.7EV, +2.0EV, -0.3EV, -0.7EV, -1.0EV, -1.3EV, -1.7EV, -2.0EV.



• White Balance

The White Balance function allows you to adjust the camera setting according to the lighting in your scene when recording still images and movies.

- As you move through each selection, you can see the preview on the LCD display.




Icon	Item	Description
	Auto	The camera automatically adjusts the white balance. This should be used for most photographic scenes.
	Daylight	Ideally used for bright sunny conditions.
	Cloudy	Ideally used for cloudy conditions.
	Tungsten	Ideally used for indoor photos with tungsten or halogen lighting without a flash.
	Fluorescent 1	Ideally used for indoor photos with reddish fluorescent lighting conditions. This is considered "warm" lighting.
	Fluorescent 2	Ideally used for indoor photos with bluish fluorescent lighting conditions. This is considered "cool" lighting.
	Custom	Used when light source cannot be specified. Press the shutter button on the camera to automatically adjust the appropriate white balance setting according to the scene.

• ISO

The ISO function lets you adjust the ISO sensitivity in recording still images depending on the lighting levels of your surroundings.

- Use a higher ISO setting in dim conditions and a lower ISO setting in brighter conditions.
- As you move through the selections, the preview on the LCD display changes.
- Available settings are: Auto, 50, 100, 200, 400, 800, 1600, 3200 (3M, 16:9 <2M>, VGA), 6400 (16:9 <2M>, VGA).



NOTE:

If the ImageStabilizer is enabled, ISO is automatically set to Auto and cannot be adjusted. To adjust ISO, disable Stabilizer first.

• Metering

The Metering function lets you select the area of the subject or frame by which the camera measures light to record still images or movies.

- As you move through the selections, the preview on the LCD display changes.




Icon	Item	Description
	Multi	The camera measures the exposure readings from multiple points in the subject area.

Icon	Item	Description
	Center	The camera measures the average light from the entire frame but gives more importance to the values near the center.
	Spot	The camera selects the exposure value based on the center of your picture.

• Color Mode

The Color Mode function lets you record still images or movies and apply different colors or tones for a more artistic effect.

- As you move through the selections, the preview on the LCD display changes.



Icon	Item	Description
	Normal	The camera records normally.
	Vivid	The camera captures the image with more contrast and saturation emphasizing bold colors
	Sepia	Images are captured in sepia tones.
	B&W	Images are captured in black and white.
	Vivid Red	Captured image becomes reddish. Ideally used to record images like flowers and cars to make them more vivid.
	Vivid Green	Captured image becomes greenish. Ideally used to record images like mountains and lawns to make them more vivid.
	Vivid Blue	Captured image becomes bluish. Ideally used to record images like the sky and the ocean, to make them look more vivid.

• Using the Record Menu



If you are in Record mode, you can access the Record menu simply by pressing the MENU button on your camera.

MENU


When the menu is displayed, use the 4-way navigation control and the OK button to move through menu selections and apply your desired settings. To close the menu anytime, press the menu button again.


• Record Menu

The Record menu allows you to change modes, and setup other capture settings.

To go to Record Menu:

Set the camera to Record mode. See “Switching between Record Mode and Playback Mode” on page 20.


1. Press  to launch Record Menu
2. Use the ▲ or ▼ keys to move through the menu selections.
3. To select an item, press ⏏.
4. Press the OK button to save and apply settings.























• Setting the Scene Mode

Setting the Scene mode allows you to capture images with the cameras' presets according to the scenes or environment.

1. From the Record Menu, press ⏏ to select Record Mode.
2. Use the navigation controls to move



Icon.	Item	Description
	Kids	This feature is used to capture still images of moving kids.
	Night Scene	This feature is used to capture images with night scenery background.
	Fireworks	This feature slows shutter speed to capture fireworks explosions.
	Snow	This feature is used for snow scenes.
	Sports	This feature captures still images in high speed movements.
	Party	This feature is used for wedding or indoor party settings.
	Candlelight	This feature is used to capture warm candle light effects.
	Night Portrait	This feature is used to capture portrait pictures with night or dark background.
	Soft Skin	This feature enhances skin tone and facial skin appears smooth.
	Soft Water	This feature enhances smooth effects like water or silk.
	Food	This feature is used to capture images of food. The increased saturation in this mode makes the captured image more enticing.
	Building	This feature enhances the edges of captured images.
	Text	This feature enhances the black and white contrast normally used when capturing text images.
	Auction	Pictures taken in Auction mode are automatically saved under a specific folder named "_AUCTION".


Icon.	Item	Description
	Smile Detection	This feature uses smile tracking to automatically detect smiling faces to capture. When smiles are detected, it continuously captures the image.
	Blink Detection	This feature detects if the subject blinked their eye when the image is captured and gives the user an option whether to save it or not.
	Pre-composition	This feature captures a image temporarily as a reference. Review the temporary image, when satisfied, take another picture to capture you final image.
	Love Portrait	This feature uses face tracking to auto detect faces to capture portraits photos without the help of others. When more than two faces are detected, AF is automatically activated. The camera starts a count down and captures a picture in two seconds.
	Camcorder	This mode is used to record movie clips.
	Voice Recorder	This mode is used to record audio clips.

After selecting the scene mode, the selected mode, except Voice Rec, will be added to the forefront in MyMode of Function Menu. See "Using the Function Menu" on page 31.


Using Smile Capture Mode

The Smile Capture mode uses smile tracking to automatically capture images. This feature is most useful in capturing different angles and smiles of moving people. When capturing an image with more than one person, the camera detects the smile of the closest person in the center of the screen.

To activate Intelligent Scene

1. Select  from the Scene Mode submenu.
2. Focus the camera on the subject to capture.
3. The camera detects the shooting conditions and switches to the appropriate scene mode.
4. Press the shutter button halfway down to allow the camera to focus on the subject. The frame turns green to indicate focus is set.
5. Press the shutter button to take the shot.







The camera displays a solid white frame when a face is detected.



NOTE:

When Intelligent Scene function is enabled, icons will be displayed even in the Guideline, or No Display modes are enabled when the shutter button is pressed halfway down.

The table below shows the modes supported by Intelligent scene:

Icon.	Intelligent Scene Modes	Description
	Portrait	This mode is set when a face is detected.
	Landscape	This mode is set when: <ul style="list-style-type: none">• There is no face detected.• The focus distance is more than 1.5 meters.• The EV setting is greater than 11 or 10.5.
	Sunset	This mode is automatically set when sunset lighting is detected.
	Macro	This mode is set when: <ul style="list-style-type: none">• There is no face detected• The focus distance is within the macro range. This mode can only be detected when you half press the shutter button.
	Blacklight	This mode is set when a face is detected with an EV setting greater than 2.5.
	Backlight Portrait	This mode is set when a face is detected with an EV setting greater than 2.5.


• Setting the AEB

AEB stands for Automatic Exposure Bracketing. This feature captures the same image with 3 different exposure settings.

- As you move through the selection, the preview on the LCD display changes.

To set AEB

1. From the Record menu, select AEB.
2. Use the ▲ or ▼ keys to go through the selection.
3. Press the OK button to save and apply changes.




• Setting the AF Area



AF stands for Automatic Focus. This feature determines the area on which the camera focuses.

To set AF Area

1. From the Record menu, select AF Area.
2. Use the ▲ or ▼ keys to go through the selection.
3. Press the OK button to save and apply changes.



The table below shows the available AF area settings.

Icon	Item	Description
	Wide	The camera automatically selects focus area within the wide frame.
	Center	The focus area is fixed on the center.


• Setting the AF Lamp

The AF Lamp function allows you to record images even in low light conditions.

If AF Lamp is set to Auto, the AF lamp located in the front of the camera, see “Front View” on page 12, emits a red light by pressing the shutter button halfway down allowing the camera to set the focus easily.

To set AF Lamp

1. From the Record menu, select AF Lamp.
2. Use the ▲ or ▼ keys to go through the selection.
3. Press the OK button to save and apply changes.




• Setting Sharpness




This function allows you to enhance or soften finer details of your photos.

To set Sharpness

1. From the Record menu, select Sharpness.
2. Use the ▲ or ▼ keys to go through the selection.
3. Press the OK button to save and apply changes.



The table below shows the available AF area settings.


Icon	Item	Description
	High	Sharpens the image.
	Normal	Normal sharpness.
	Low	Softens the image.

• Setting Saturation

The Saturation function lets you adjust the color saturation in your photos. Use a higher saturation setting for rich colors and a lower saturation setting for more natural tones.

To set Saturation

1. From the Record menu, select Saturation.
2. Use the ▲ or ▼ keys to go through the selection.
3. Press the OK button to save and apply changes.



The table below shows the available Saturation settings.


Icon	Item	Description
	High	Enhances saturation.
	Normal	Normal saturation is applied.
	Low	Reduces saturation.

• Setting Contrast

This function allows you to adjust the contrast of your photos.

To set Contrast

1. From the Record menu, select Contrast.
2. Use the ▲ or ▼ keys to go through the selection.
3. Press the OK button to save and apply changes.



Once date and time are stamped on a photo, they can no longer be edited or deleted.

Limitations of Date Stamp functions are as follows:

- Available for still images only.
- May slow down AEB/ continuous shooting when Date Stamp is enabled in /AEB/Burst mode.
- If Date Stamp is enabled, digital zoom is automatically turned off.
- In vertical or rotated images, the date and time on your photos still appear horizontally.

To set Date Stamp

1. From the Record menu, select Date Stamp.
2. Use the ▲ or ▼ keys to go through the selection.
3. Press the OK button to save and apply changes.





• Setting the Auto Review

The Auto Review function lets you view the captured image right after shooting it.

If Auto review is On, the camera will display the captured image for 1 second on the LCD display.


To set Auto Review


1. From the Record menu, select Auto Review.
2. Use the ▲ or ▼ keys to go through the selection.
3. Press the OK button to save and apply changes.




• Recording Movies

You can record movies with the camera, the available recording time depends on the capacity of the memory card. Videos can be recorded until the maximum memory capacity has been reached. However the length of a single video may be limited depending on the camera model.

1. From the Record mode menu, select Movie.
2. Focus your camera on the subject that you want to take.
3. Press the Shutter button to start recording.
4. Use the  control to zoom in and zoom out an image.
5. To stop recording, press the Shutter button.





NOTE:


- Sound cannot be recorded while pressing the  control.
- When the maximum capacity for a single video has been reached, simply press the shutter button again to continue recording.
- Digital zoom is not available in movie recording.
- Power save is not available in movie recording or pause recording.
- The camera will automatically stop recording when the memory capacity is full.

Setting Movie Size





The Movie Size function icon appears only in Movie Mode. Use this function to adjust the resolution and quality of movie clips.

To set the Movie Size:

1. In the Movie mode press the FUNC key.
2. Press the DISP button to select the resolution.
2. Use the  or  to select your movie's resolution.
3. Press the OK button to confirm your choice.



The table below shows the available size and corresponding image quality settings.

Icon.	Frame Size	Description
	720 x 400	HDTV
	640 X 480	High Quality
	320 X 240	Normal
	640 X 480	YouTube Mode

To set other movie mode settings, please refer to " Using the Function Menu" on page 31.

YouTube Mode

YouTube Mode allows you to record movies with predefined video settings to easily upload to the YouTube website.

YouTube supports two file upload standards:

- Single File Uploader. The maximum movie file size is up to 100 MB.
- YouTube Uploader. The maximum movie file size is up to 1 GB.

Most uploaded movie length ranges within 5 minutes, although you can upload a maximum movie length of 10 minutes.

Therefore when you record using the YouTube mode, the following standards are followed:

- Recorded movies are set to YouTube standard resolution of 640 X 480.
- Recording automatically stops when the file reaches 100 MB.

Recorded movies in the YouTube mode are stored following the DCF rule, however movies are saved in a specific folder named "_UTUBE" . For more details, please refer to " Folder Structure" on page 84.

- To record a YouTube movie, select  from the Movie Size function. Available recording time for a YouTube movie is up to 10 minutes.

• Recording Voices

1. From the Record mode menu, select Voice. The Voice Recording screen layout is displayed on the LCD display.
3. Press the Shutter button to start recording.
4. Press the Shutter button to stop recording.



NOTE:

Voice recording will automatically stop when the maximum memory capacity is full.

6 Playback

View images, videos and audio clips through your camera's Playback mode.

• Viewing in Single Navigation

The Single navigation mode displays the images one by one on the LCD display. To view images/videos/audio clips, follow the steps below.

1. Press the **Play** button to set or turn on the camera to Playback mode.
2. The LCD screen displays an image. To understand the icons and other information on the screen, please see "Playback Mode Screen Layout" on page 23.

Still Image



Movie



Audio Clip



3. Touch **⏮** or **⏭** to view next/previous image/video/voice recording.
4. To play a video or a voice recording, touch the **▲** key. See "Playing Movies" on page 57 and "Playing Voice Recording" on page 58 for more details.

• Viewing Thumbnails

1. Press the **W** button twice to view 9-image thumbnails.
2. Touch **⏮** or **⏭** to view next/previous page.
3. Touch the **OK** button to select the image and view it normally.



Scroll bar. If scroll bars appear, it indicates that the screen can be scrolled.

Thumbnail view

Thumbnail icons

When you view the thumbnails, some images may contain icons. These icons indicate the type of file or recording.

Icon.	Type	Description
	Voice Memo	Indicates that a voice memo is attached to the image.
	Movie	Indicates a recorded movie. The displayed image is the first frame of the movie clip.
	Locked File	Indicates that the image has been locked. Locked files cannot be edited or deleted.
	Voice Record	Indicates a voice recording file.
	File Error	Indicates an error file.

• Zooming Images

The zoom view function works with still images only.

- In normal view, press the T button repeatedly until the desired zoom view.
- The 4 arrows on the LCD display indicate that the image is zoomed in.
- You can zoom view an image of up to 12X.




- Use the navigation controls to view the zoomed image.
- Press the Play button to close zoom view.



NOTE:


For 320 x 240 resolution images, you can only zoom in up to 6X.

• Playing Movies

1. Set the camera to Playback mode.
2. Use the navigation controls to scroll through the saved images. A movie clip has a movie icon displayed on screen. See picture on the left.
3. Press the ▲ key to play the movie.
4. During playback, press the ⏏ or ⏮ keys to fast forward or rewind the movie. The camera supports forward and rewind speed of up to 4x.
5. During playback, use the **[W]** **[T]** to control volume. Press the T button to increase volume. Press the W button to decrease volume.
6. Press the ▲ key to pause playback. Press the ▲ key again to resume. When paused, the play info will remain on screen except **[WT]** .
7. To view the movie frame by frame (forward or backward), press the ▲ key to pause playback, then press the ⏏ or ⏮ keys.
8. Press the ▼ key to stop the playback. The LCD display displays the movie frame image in Single navigation mode.



NOTE:


- The play info, except the **[WT]**  icon, will be displayed when the movie is paused, during REW/FF or frame by frame modes.
- Volume cannot be adjusted when paused or during REW/FF modes.

• To capture screenshot image from a movie clip

1. During playback of movie, press the ▲ key to pause playback on your desired movie frame to capture.
2. Press the Shutter button to capture screenshot.
3. The camera will automatically stop playback. The LCD display displays the captured image in Single navigation mode.





NOTE:

This feature does not function when the memory card is full or the folder cannot be created. The icon  does not appear on the screen either.

• Playing Voice Recording

1. Put the camera into Playback mode.
2. Use the navigation controls to scroll through the saved images. When viewing a voice recording file, the LCD display displays the screen layout of Audio clips. See picture on the right..
3. Press the ▲ key to play the voice recording.



4. During playback, use the  to control volume. The volume icon appears on the screen. Press the T button to increase volume. Press the W button to decrease volume.
5. Press the ▲ key to pause playback. Press the ▲ key again to resume. When paused, the play info will remain on screen except .
6. Press the ▼ key to stop the playback. The LCD display displays the image in Single navigation mode.





NOTE:

Volume cannot be adjusted during pause or REW/FF modes.

• Playing Voice Memo

Voice memo is recorded and attached separately to a captured image. See “Voice Memo” on page 67 on how to record voice memo.

1. Set the camera to Playback mode.
2. Use the navigation controls to scroll through the saved images. An image file with voice memo has a voice memo icon located on the top center of the LCD display. See picture on the right.
3. Press the ▲ key to play the voice recording.
4. During playback, use the  to control volume. The volume icon appears on the screen. Press the T button to increase volume. Press the W button to decrease volume.
5. Press the ▲ key to pause playback. Press the ▲ key again to resume. When paused, the play info will remain on screen except .
6. Press the ▼ key to stop the playback. The LCD display displays the image in Single navigation mode. Single navigation mode.



NOTE:



Volume cannot be adjusted when you pause the voice memo.





• Deleting an Image/Video/Audio


There are two ways to delete an image/video/audio:

- Using the Delete button, or
- Using Playback Menu Delete settings. See “Deleting Files” on page 61.

Using the Delete Button

 Use the Delete button on your camera to delete or mark an image
FUNC.  video audio clip for deletion.





1. Set the camera to Playback mode.
2. View images/videos/audio clips in Single navigation mode.
3. Use the  or  keysto scroll the display.
4. When the desired image/video/audio clip is displayed on the LCD display, press the Delete button.
5. A confirmation selection appears on screen.
6. Select Delete.
7. Press the OK button to delete.
8. The next image is displayed on the LCD display. To delete another file, use the  or  keys to scroll through the images/videos/audio clips. Then, repeat steps 4 to 7.
9. To close the Delete function and go back to viewing in single navigation mode, select Cancel.



• Setting Playback Menu

The Playback menu allows you to edit images, delete files, records voice memo, and setup other playback settings.

To go to Playback Menu:

1. Set the camera to Playback mode.
2. Press  to launch the Playback Menu.
3. Use the  or  keys to go through the selection.
4. To select a menu, press  or the OK button.
5. Change the submenu settings using the 4-way navigation control.
6. Press the OK button to save and apply settings.




• Setting Slideshow

The Slideshow function allows you to view all stored photos/videos in still image format in a continuous sequence.

To view slideshow:

1. From the Playback menu, select Slideshow. The Slideshow menu appears.
2. Set the slideshow settings.
3. Select Start, then press the OK button to start the slideshow.
4. During slideshow, press the OK button to pause slideshow.
5. Use the ▲ or ▼ keys to move through the options. Select whether to Continue or Exit the slideshow.
6. Press the OK button to apply selected option.



To view slideshow:

1. From the Slideshow menu, use the ▲ or ▼ keys to move through the selections.
2. Select Interval setting. Press the 🔼 or 🔽 keys to adjust. Choose among the available interval settings: 1 sec., 3 sec., 5 sec., and 10 sec.
3. Select Transition setting. Press the 🔼 or 🔽 keys to adjust. Choose among the available transition settings:
 - Horizontal
 - Shrink
 - Fade
 - Random
4. Select Repeat setting. Press the 🔼 or 🔽 keys to adjust. Available settings are: Yes, No.


• Deleting Files

The Delete function lets you remove unwanted files in the internal memory or on the memory card. Protected files cannot be erased, to delete, unprotect the file first. See "Protecting/Unprotecting Files" on page 64.





To delete a photo/video/audio clip:


1. From the Playback menu, select Delete.
2. The Delete submenu is displayed on the LCD display. Select available settings:

- **Single.** Select one file to delete.
- **Voice Only.** Delete only the attached voice memo, the image is retained in the memory.
- **Multi.** Select multiple files to delete at the same time.
- **All.** Delete all files.








To delete a single file:

1. Select Single in the Delete submenu, the images are displayed on the LCD display in single navigation mode.
2. Use the  or  keys to scroll the display.
3. When the desired image/video/audio clip is displayed on the LCD display, select Delete.
4. Press the OK button to delete.
5. The next image is displayed on the LCD display. To delete another file, use the  or  keys to scroll through the images/videos/audio clips. Repeat steps 3 to 7.
6. To close the Delete function and go back Playback menu, select Cancel.



To delete attached voice memo:

1. Set the camera to Playback mode.
2. View images/videos/audio clips in Single navigation mode.
3. Use the  or  keys to scroll until the desired image with voice memo is displayed on the screen.
4. Press  to launch the Playback Menu.
5. Use the  or  keys to move through the Playback menu selections then select Delete.
6. From the Delete submenu, select Voice only.
7. A confirmation selection appears, select Delete.
8. Press the OK button to delete the attached voice memo and go back to Playback mode.




NOTE:

The Voice Only submenu is disabled if the current image displayed, at the time you access the Delete menu, does not have any attached voice memo.


To delete multiple files:

1. Select Multi in the Delete submenu, the images are displayed in thumbnail view on the LCD display.
2. Use the navigation control to move through the files.
3. When the desired image/video/audio clip is highlighted, press the OK button to mark image/ video/audio clip for deletion.
4. Repeat step 3 until all desired images for deletion are marked.
5. Press the MENU button. A confirmation selection appears.
6. Select Yes to confirm.
7. Press the OK button to delete marked files.



To delete all files:

1. Select All in the Delete submenu. A confirmation message appears.
2. Select Yes.
3. Press the OK button to delete all files.




• Protecting/Unprotecting Files



The Protect function lets you lock a file to protect it from being modified or accidentally erased. A protected file has a lock icon when viewed on Playback mode.


To protect files:

1. From the Playback menu, select Protect.
2. The Protect submenu is displayed on the LCD display. Select available settings:
 - **Single.** Select one file to Lock.
 - **Multi.** Select multiple files from the thumbnail view to lock.
 - **Lock All.** Lock all files.
 - **Unlock All.** Unlock all files.




To protect/unprotect a single file:

1. Select Single in the Protect submenu, the images are displayed on the LCD display in single navigation mode.
2. Use the  or  keys to scroll
3. When the desired file is displayed on the LCD display, select Lock/Unlock.
4. Press the OK button to protect/unprotect the file and go back to Playback mode.




To protect/unprotect multiple files

1. Select Multi in the Protect submenu, the images are displayed in thumbnail view on the LCD display.
2. Use the navigation control to move through the files.
3. When the desired file is highlighted, press the OK button to mark/unmark the file clip for protection.
4. Repeat step 3 until all desired files to protect are marked.
5. Press the MENU button. A confirmation selection appears.
6. Select Yes.
7. Press the OK button to lock files and go back to Playback mode.




To protect all files

1. Select Lock all in the Protect submenu. A confirmation message appears.
2. Select Yes.
3. Press the OK button to Lock all protected files.



To unprotect all files



1. Select Unlock all in the Protect submenu. A confirmation message appears.
2. Select Yes.
3. Press the OK button to unlock all protected files.




• Red-Eye Correction

The Red-Eye Correction function is used to reduce red-eye in captured images. This function is only available for still images. Red-eye correction can be applied to an image several times, but the quality may gradually deteriorate.

To activate Red-Eye Correction:

1. Set the camera to Playback mode.
2. Press the  or  keys to scroll and select an image.
3. Press the MENU button to launch the Playback menu.
4. Select Red Eye Correction.
5. Select Start.
6. Press the OK button to start correction.



Steps 5 and 6



Step 7





7. After completing Red eye correction, a menu selection appears. Select whether to:
 - **Overwrite.** Save and replace the old file with the new one.
 - **Save As.** Save the new file as a new one.
 - **Cancel.** Cancel red eye correction.
8. Press the OK button to save/cancel changes.

• Voice Memo

The Voice Memo function allows you to record and attach a voice memo to a saved image. You can record a maximum of 30 seconds of Voice memo per image. This function is only available in still images.

To record voice memo:

1. Set the camera to Playback mode.
2. Press the  or  keys to scroll and select an image.
3. Press the MENU button to launch the Playback menu.
4. Select Voice Memo.
5. Select Start, then press the OK button to start recording.



Time left (n seconds) for recording.

6. Select Stop, then press the OK button to stop recording.



NOTE:

When you record voice memo to an image with an existing voice memo, the old recording is automatically changed to the new one.





• Photo Editing



The Photo Edit function lets you adjust edit still images to apply different colors or tones for a more artistic effect. Edited photos in this function is saved as a new file.

• Trim

The Trim function allows you to trim an image to another image size. This function is only available for still images.

To trim an image:

1. Set the camera to Playback mode.
2. Press the  or  keys to scroll and select an image to trim.
3. Press the MENU button to launch the Playback menu.
4. Select Trim. The Trim screen layout is displayed on the LCD display.
5. Use the   control to change size.



6. Use the navigation controls to move the image.
7. Press the OK button to apply changes. A menu selection appears.
8. Select whether to:
 - **Overwrite.** Save and replace the old file with the new one.
 - **Save As.** Save the new file as a new one.
 - **Cancel.** Cancel trim.
9. Press the OK button to save/cancel changes.



**NOTE:**



- Trim function is not available for photos with image size set to VGA.
- All images will be trimmed in 4:3 ratio regardless of its original image ratio.

• Resize

The Resize function allows you to change the image resolution of large images to smaller ones. This function is only available for still images.

To resize an image:



1. Set the camera to Playback mode.
2. Press the or keys to scroll and select an image to resize.
3. Press the MENU button to launch the Playback menu.
4. Select Resize. The Resize submenu is displayed on the LCD display.
5. Select size among: 8M, 5M, 3M, and VGA. Available size settings may vary depending on original image size. Unavailable settings appear as gray icons in Resize submenu.
6. After selecting size, a menu selection appears. Select whether to:
 - **Overwrite.** Save and replace the old file with the new one.
 - **Save As.** Save the new file as a new one.
 - **Cancel.** Cancel resize.
7. Press the OK button to save/cancel changes.

**NOTE:**

Resize function is not available for photos with image size set to VGA.

• Setting Startup Image

The Startup Image function allows you to setup a startup image when you turn on your camera.

1. Press the MENU button to launch the Playback menu.
2. Select Startup Image. The menu selection appears.
3. Select options:
 - System. Use camera default image.
 - My Photo. Use the  or  keys to scroll and select desired image.
 - Off. Disable the startup image.
4. Press the OK button to apply changes.



NOTE:


The startup image will still be displayed startup even if the selected image was deleted.

• Setting DPOF





The Digital Print Order Format (DPOF) function allows you to mark still images in your memory card for printing and allows you to specify the number of copies that you want to print at a later date. When all images to be printed are marked, take the memory card to a digital printing service, or use a DPOF compatible printer.

To set DPOF

1. Press the MENU button to launch the Playback menu.
2. Select Startup Image. The submenu appears. Available settings are as follows:
 - Single. Select a single image to mark.
 - All. Mark all images in the memory card.
 - Reset. Reset all DPOF settings to initial default settings.



To set DPOF on a single image/all images:

1. Select Single or All on the DPOF submenu.
2. For single image, use the  or  keys to scroll and select an image to mark for printing.
3. Specify the number of copies. Use the  or  to increase/decrease number.
4. Press the FUNC button to toggle between turning on/ off the date stamp.
5. Press the OK button to save DPOF settings.



To reset DPOF

1. Select Reset on the DPOF submenu. A confirmation message appears.
2. Select Yes.
3. Press the OK button to reset DPOF settings.



NOTE:


You can specify up to 99 copies for DPOF. If you specify 0 copies, the DPOF setting of that image is automatically disabled.

• PictBridge

The PictBridge function allows you to print images captured by your camera without connecting the camera to a PC. Print images with a PictBridge compatible printer directly.

To activate PictBridge:

Connect your camera to a PictBridge compatible printer using the USB cable. See illustration below.










NOTE:


If the printer does not support date stamp, the date stamp function will be disabled in PictBridge.

7 Using the Setup Menu

You can access the Setting menu whether you are in Record or Playback mode. The Setting menu allows you to configure general camera settings.

To go to Setting Menu:


1. Press  to launch the Record/Playback Menu.
2. Use the  or  keys to change the menu tab to Setup  menu.
3. Use the  or  keys to move through the menu selections.
4. To select an item, press the OK button or .
5. Change the submenu settings using the 4-way navigation control.
6. Press the OK button to save and apply settings.



• Setting Sound

Use the Sound menu function to control the sounds produced by the camera.

1. From the Setting menu, select Sound.
2. Adjusts sound settings.
3. Press the SET button to apply changes.



Item	Available Settings	Description
Startup	Sound 1, Sound 2, Sound 3, Off	Selects the startup sound when camera is turned on.
Shutter	On, Off	Enables or disables shutter sound when shutter button is pressed. Shutter sound is not available when recording movies or voice clips.
Operation	On, Off	Enables or disables operation sound.
Volume	0-4	Adjusts volume.


• Setting Power Save

The Power Save function allows you to set an idle time after which the camera automatically sets to sleep mode to save power. After a minute of being in the sleep mode, the camera eventually turns off power.

Available settings are: 1 min., 3 min., and 5 min.

This function is not available in the following instances:


- Recording a movie or audio file
- Playing a slideshow/movie/audio file
- Using the USB connector.



• Setting LCD Save

Enable the LCD Save function to automatically decrease the LCD brightness to conserve battery power. When the camera is idle for 20 seconds, the LCD darkens. Press any button to resume to normal brightness.


- The camera is idle when no buttons are pressed. LCD Save, though enabled, does not function during movie playback, slideshow, and video recording.



• Setting Date & Time

Use the Date & Time function to set the date and time of your camera. This function is useful in attaching date stamps on captured images. Your camera uses a 24-hour time format.

1. Press the navigation controls to adjust date and time value. By holding down the ▲ or ▼ keys, the numeric values changes continuously.
2. Touch OK to apply changes.



• Setting Language



The Language function allows you to choose the language of the on screen display (OSD) menu.


1. Use the navigation control to scroll through the list and select the desired language.
2. Press the OK button to confirm and apply settings.



• Setting File Numbering

This function allows you to select the method in which to assign file numbers to images. Available settings are:

-  Series. Assigns number to files in sequence even if the folder is changed.
-  0001 Reset. Starts from 0001 each time the folder is changed.





To understand folder and file structure of your camera, see “About Folder and File Names” on page 84.

• Setting TV Out



Use the TV Out function to adjust video output signal to accommodate different regional settings. If TV out is not set correctly, the image may not display properly on TV.

Available settings are:

-  **NTSC** NTSC. Applicable in Japan, USA, Canada, Taiwan and others.
-  **PAL** PAL. Applicable in Europe, Asia (excluding Taiwan), Oceania and others.

• Setting LCD Brightness

Use the LCD Brightness function to control the LCD brightness. Available settings are:

-  **Bright**. Enhances LCD brightness.
-  **Normal**. Normal LCD brightness.

• Setting Battery Type




Use this function to select the battery type used for the camera. Note: It is important to select the correct battery type in the SETUP menu for this product.

• Setting Memory Kit

Use this function to manage contents of the internal memory or memory card.

Available settings are:

- **Format**. Select to format the currently used memory (internal camera or SD card).
- **Copy to Card**. Select to copy all files stored in the internal memory to the memory card.





NOTE:

- If there is a memory card inserted in the memory slot, the camera automatically saves all files to the memory card.
- If there is no memory card or the internal memory is empty, the Copy to Card function is disabled.

• **Reset All**

Use this function to reset the camera to its factory settings. However, the following settings are exceptions and not affected by Reset.

- Date and Time
- Language
- TV Out
- Custom White Balance data



Need help with your digital camera?

Call our toll-free customer service number. Look for the insert with this icon:



Or visit www.polaroid.com.

8 Installing the Software onto a Computer

• Installing the Software

For Windows® Users:

PC



NOTE:

- If you don't know how to install the software, please read the "Read Me" file on the CD first.
 - Windows 98SE needs to install your digital camera Driver for the Mass Storage function. After the installation, please restart your computer before connecting your camera to the computer.
 - Windows Me, 2000, XP, and Vista do not need to install the driver. Plug in the camera to the computer to transfer or edit your photos and video clips.
 - For better quality graphics and sound when watching your video clips on the computer, it is recommended to install DirectX version 9.0 or above. To download, visit www.microsoft.com
1. Before you begin, close all other software applications open on your computer.
 2. Insert the camera CD into your computer CD-ROM drive.
 3. The CD User Interface screen will automatically launch. (If the setup screen does not appear after loading the CD, you can open Windows Explorer, double click on the "INSTALL-E.exe" in the CD folder to start the setup.
 4. Click on each software interface button in turn and follow the on-screen instructions.

For Macintosh Users:

Mac

1. Before you begin, close all other software applications open on your computer.
2. Insert the CD supplied into the computer CD-ROM Drive.

3. Double click the CD-ROM icon "Polaroid" .
4. Install the software included.

• Software Included with Your Camera

The i1237 software CD contains the following software:

Polaroid Digital Camera Driver

Driver is ready for Windows 98se Users only. Your computer need to be installed this driver to gain camera's mass storage function in Windows 98se.

ArcSoft MediaImpression™:

Manages your media for you, and gives you tons of fun and exciting ways to create and share projects featuring your photo, video, and music files. Edit, enhance and add creative effects to your photos. Create your own movies or photo slide shows, complete with soundtrack. Upload your files easily to YouTube™! Or share them through simple email attachments or popular photo printing.

ArcSoft Print Creations™:

A family of fun and easy print-project software that brings out the creativity in you.

Print Creations brings together ArcSoft's latest printing applications into one great user experience. Starting from the Print Creations Launch Pad, you can access any of ArcSoft's great new printing applications including: Greeting Card, Photo Calendar, Album Page and more. Projects can be printed at home or saved as image files for sharing with family and friends by email or the web.

Each unique print-project software comes packed with a full set of professionally designed templates and layouts for all occasions and in all kinds of styles. You can personalize the designs with your own digital pictures and text.

Adobe® Acrobat® Reader™ .PDF File Reading Software

Adobe® Acrobat® Reader™ lets you view and print Adobe Portable Document format (PDF) files on all major computer platforms, as well as fill in and submit

Adobe PDF forms online.



NOTE:

- Please access <http://www.arcsoft.com/> to learn more about ArcSoft software.
- ArcSoft MediaImpression & PrintCreations don't support Windows 98se/Me.

• **Fast and Easy YouTube™ Upload**

1. Install ArcSoft software on included CD-ROM.
2. Download movie files from your digital camera to your computer.
3. Open ArcSoft software and select "Video".
4. Select the movie file you want to upload and click "Upload to YouTube" icon.
5. Enter your YouTube account information. If you do not have a YouTube account, visit www.youtube.com <<http://www.youtube.com/>> to register for a free account.

• **System Requirements**

In order to get the most out of your camera, your computer must meet the following system requirements:

For Windows:

- Windows 98se/Me/2000/XP/Vista
- Processor:Pentium III 1G or above
- Memory: 512MB or above
- HDD space: 500 MB or above
- 16 bit color display display
- Microsoft DirectX 9.0C
- USB port and CD-ROM drive

For Macintosh

- Power Mac G3 or later
- Mac OS 10.3-10.5
- Memory: 256MB or above

- HDD space: 500MB or above
- USB port and CD-ROM drive

• Uninstalling Polaroid i1237 Camera Driver

For Windows® Users only

1. Open Add/Remove Program Properties in Control Panel and select “Polaroid Digital Camera” program, then click “Add/Remove” button.
2. The confirmation dialogue box appears, please click “Yes” to confirm removing the camera driver.
3. The un-installation program runs automatically, please restart your computer when it is finished.

Need help with your digital camera?

Call our toll-free customer service number. Look for the insert with this icon:



Or visit www.polaroid.com.

9 Making Connections


You can connect your camera to:

- TV
- Computer
- Printer

• Connecting the Camera to a TV

To connect your camera to a TV:


1. Turn on the camera.
2. Set the TV out to match TV's video out format. See "Setting TV Out" on page 76.
3. Connect the USB/AV 3-in-1 cable to the USB port on the bottom of your camera.
4. Connect the other end of the cable to the TV's AV input port.
5. The LCD screen turns black and all images and video clips are displayed on the TV.



• Connecting the Camera to a PC

You can transfer photos, videos and audio files to your PC.

1. Connect the camera to a PC using the USB cable.
2. Turn on the camera.
3. The PC detects the connection. The camera's internal memory and memory card display as removable drives in the file manager. No image is displayed on the




LCD display.

- **Connecting the Camera to a Printer**

You can print your photos directly using a PictBridge compatible printer.

1. Turn on your camera.
2. Set PictBridge settings.
3. Connect the camera to the printer using the USB cable.



For more details on how to print photos, see " PictBridge" on page 72.

10 Appendix


• About Folder and File Names

Your camera automatically creates specific directory of folders in the internal memory or memory cards to organize captured images, videos and audio files.

Folder Structure

Your camera creates three directory names:

- **DICAM.** All captured images, videos and audio files are stored in this folder except for files recorded using the Auction or YouTube mode.
- **_AUCT.** Captured images using the Auction mode are saved in this folder.
- **_UTUBE.** Captured videos using the YouTube mode are saved in this folder.



Folder names begin with a 3-digit number from 100 to 999 and followed by "DICAM" or "_AUCT" or "_UTUBE". Each folder holds up to 9999 files. If new files are saved, a new folder named in sequence will be automatically created.

File Naming

File names begin with "DSCI" and followed by a 4-digit number that increases in sequence. File numbering starts from 0001 when a new folder is created. If the highest folder number is 999 and the highest file number exceeds 9999, the camera will display the warning message "Folder cannot be created."

When this happens, try one of the following ways:

- Reset the file number.
- Plug in a new memory card.



NOTE:

Do not change the folder and file names in the memory card using your PC. It may be unable to playback the data using the camera.

Need help with your digital camera?

Call our toll-free customer service number. Look for the insert with this icon:



Or visit www.polaroid.com.

12 Getting Help

• Polaroid Online Services

Website: <http://www.polaroid.com>

• ArcSoft Software Help

For United States

ArcSoft HQ Support Center
(Fremont, CA 94538)
Tel.: 1-510-979-5599
Fax: 1-510-440-7978
E-mail: support@arcsoftsupport.com
Web: <http://www.arcsoft.com/en/support/>

For Europe

ArcSoft Europe Support Center
(Ireland)
Tel.: +353-(0) 61-702087
Fax: +353-(0) 61-702001
E-mail: eurosupport@arcsoft.com

For Japan

ArcSoft Japan Support Center (Tokyo)
Tel.: +81-3-5795-1392
Fax: +81-3-5795-1397
E-mail: support@arcsoft.jp
Web: <http://www.arcsoft.jp>

For Latin America

E-mail: latinsupport@arcsoftsupport.com

For China

ArcSoft China Support Center
(Hangzhou)
Tel.: +86-571-88210575
E-mail: support@arcsoft.com.cn
Web: <http://www.arcsoft.com.cn/new/support>

For Taiwan

ArcSoft Taiwan Support Center (Taiwan)
Tel.: +886-(0) 2-2506-9355
Fax: +886-(0) 2-2506-8922
E-mail: support@arcsoft.com.tw
Web: www.arcsoft.com.tw

Visit <http://www.arcsoft.com> for technical support and frequently asked questions (FAQ's).



(c)2009 Polaroid by  Polaroid All rights reserved

"Polaroid" and "Polaroid and Pixel" are trademarks of PLR IP Holdings, LLC, used under license.

13 Specifications

• Specifications

Sensor	12 Megapixels CCD, Size: 1/2.3
Lens	Focal Length: f = 6.2 - 18.6 mm, 3X optical zoom, 5x digital zoom
LCD Display	Display: 2.7" color LCD
Focus Range	Normal: 80cm - Infinity Macro Wide: 5cm - 100cm Tele: 30 - 100cm
OSD Language	English, French, Spanish, German, Italian, Russian, Portuguese, Brazil Portuguese, Dutch, Turkish, Polish, Hungarian, Romanian, Czech, Bulgarian, Croatian, Slovak, Slovenian, Greek, Swedish, Norwegian, Finnish, Danish, Arabic, Indonesian, Malay, Thai, Japanese, Korean, Simplified Chinese, Traditional Chinese
Aperture	F = 3.0 - 5.6
Shutter	Type: Mechanical and Electronic Shutter Speed: Auto: 1 - 1/2,000 sec. Manual: 8 - 1/2,000 sec. Night: 8 - 1/2,000 sec. Fireworks: 2 sec.
File Format	Still Image: EXIF 2.2 compatible format (JPEG compression) Video: AVI (MJPEG) Audio: WAV
ISO	Auto, 50, 100, 200, 400, 800, 1600, 3200 (3M, 16:9<2M>, VGA), 6400 (16:9<2M>, VGA)
Exposure Compensation	-2EV to + 2EV (1/3EV steps)
Metering	Multi, Center, Spot
Flash Mode	Auto, Red-eye Reduction, Forced On, Slow Sync, Forced Off

- Camera Default Setting

Camera Mode	Description	Default
Still Image Mode	Image Resolution	12M
	Quality	Fine
	Metering	Multi
	White Balance for Pictures	Auto
	ISO	Auto
	Effect	Normal
	AF Area	wide
	Flash Intensity	Auto
	EV Compensation	0EV
	Photo Frame	N/A
	Sharpness	Normal
	Saturation	Normal
	Contrast	Normal
	Date Stamp	Off
	Focus Mode	Normal
	Drive Mode	Off
	Flash	Auto
AF Lamp	Auto	

Questions? Need some help?

This manual should help you understand your new product. If you have questions, call our customer service help number. Look for the insert with this icon:



or visit www.polaroid.com.

US0709
Part No.: UMI1237US001

